



## MOL Grill Gas Cylinder MANUAL

We would like to provide assistance for the installation and handling of the grill gas cylinder you have purchased, as follows:

The quick-connect grill gas cylinder can only be operated with the pressure reducer included in the set; it cannot be physically connected to other types of pressure reducers.

Contents of the pressure reducer set:

- 1 pc Reca-Cavagna type quick-connect pressure reducer (operating pressure: 29 mbar, capacity: 1.8 kg/h)
- 1 pc flexible gas hose for connection to the gas appliance (grill) (length: 1.2 m)
- 1 pc clamp for connecting the gas hose and the pressure reducer (factory-fitted)
- 1 pc clamp for connecting the gas hose to the gas appliance
- 1 pc 7.0 mm open-end wrench
- 1 pc user manual.

Steps for installing the grill gas cylinder:

1. Secure the free end of the gas hose to the connection point of the gas appliance (grill) with the clamp provided in the set. Before connecting, please read the documentation containing the instructions for use of the gas appliance.
2. Remove the shrink film from the valve of the grill gas cylinder, then remove the plastic cap providing mechanical protection from the connector.
3. Unlike traditional threaded valves, no sealing ring is required for the grill gas cylinder; the gas-tight connection is ensured by the seals inside the valve.
4. To safely connect the pressure reducer, place the grill gas cylinder on a horizontal surface. Ensure that the grill gas cylinder always remains upright during use!
5. Before connecting the pressure reducer, adjust the rotatable valve opener to a position where the green mark is upwards. (see below: *Ábra 1*) In this position, the valve is closed, and the pressure reducer can only be connected to the cylinder valve at this position.
6. Press the pressure reducer onto the valve stem with a firm motion; a click indicates the correct connection. (see below: *Ábra 2*)
7. You can open the valve by turning the valve opener; in this case, the red flame indicator should be above. (see below: *Ábra 3*)
8. After opening the valve, check the connections and the tightness of the gas appliance using a leak detection spray or soapy water. If a leak is detected, close the valve! (with

the green mark upwards) If you are unable to eliminate the leak, seek professional assistance!

9. Removing the pressure reducer: close the valve (with the green mark upwards), then press the valve in the direction indicated by the arrow (see below: Ábra 4) to remove the pressure reducer from the valve. Both the grill gas cylinder valve and the pressure reducer are closed at this point. (The pressure reducer can only be removed from the grill gas cylinder in this position.)
10. If the grill gas cylinder is empty or not in use, please replace the protective cap on the valve stem.
11. Always follow the operating instructions for the gas appliance when using it!
12. In case of fire or emergency, notify the fire department at 105 or 112!



1. ábra



2. ábra



3. ábra



4. ábra